



## GUANGZHOU TESTING CENTER OF INDUSTRIAL MICROBIOLOGY TEST REPORT

Date Received: Sept. 14, 2018

	Date Analyzed: Sept. 26, 2018			
Airfree Air Sterilizer	Source of Sample	Delivery		
Jebsen Consumer Products (China) Company Limited	Client	Lao Yanyi		
Airfree Produtos Electronicos, S.A.,	Brand	AirFree		
P125	Quantity of Sample	1PC		
	State of Sample	Machine		
	Packing of Sample	In box		
	Jebsen Consumer Products (China) Company Limited  Airfree Produtos Electronicos, S.A.,	Airfree Air Sterilizer  Jebsen Consumer Products (China) Company Limited  Airfree Produtos Electronicos, S.A.,  P125  Quantity of Sample  State of Sample		



Sample Picture

- Standard and Methods

  1. GB/T 18801-2015 Air cleaner
  2. GB 21551.3-2010 Antibacterial and cleaning function for household and similar electrical appliances-Particular requirements of air cleaner

  Items of Analysis

  Eliminating Bacterial Rate (Escherichia coli 8099)
- Remarks

  This report replaces the report KJ20181600(R) issued on October 16, 2018, and the original report is invalid.

\*\*\*To be continued\*\*\*









Date Received: Sept. 14, 2018 Date Analyzed: Sept. 26, 2018

## Test Method for Air Purifier Disinfection Performance:

Test Equipment

1) Strain: Escherichia coli

Microbial aerosol generator: TK-3 2)

3) Culture media: NA

4) Sampling equipment: six-stage sieve sampler

**Test Conditions** 

The volume of the test chamber: 3 m<sup>3</sup> 1)

2) Environment temperature: (20~25) °C

Environment humidity: (50~70) %RH

Operation Conditions of the Air Purifier The test process was electrified.

Test Procedure

Get a bacteria slant culture (4~7 generation) which is incubated at 37 °C for 24 h, wash the culture from this slant with 10 mL NB, filter the liquid culture by aseptic cotton buds, and dilute this inoculums with NB as appropriate.

The equipments are placed in the test chambers, close the door, and turn on the HEPA filter system. Simultaneously operate the environmental control devices until the temperature reaches 20 °C~25 °C,

relative humidity reaches 50-70%. Turn off the chamber environmental control system.

Release microbial aerosol: turn on the microbial aerosol generator, then turn on the ceiling fan, turn off 3) the fan after 10 min, and let stand for 15 min.

4) Original bacteria aerosols collected by six-stage sieve sampler.

Turn on the fan during the test. The air purifier are adjusted to the highest air cleaning mode setting for test (test group). Bacteria aerosols (control group and test group) are collected at 60 min .

Choose 2 NA plates (the same batch) as the negative control, and culture them on the same condition

with the samples.

Run the test three times and take the mean as the final result.

5. Computational Formula

Natural decay rate 
$$N_i(\%) = \frac{V_0 - V_i}{V_0} \times 100$$

Where:  $V_0$  = original bacteria count of control group;  $V_t$  = bacteria count after treatment of control group.

Killing Rate 
$$K_t(\%) = \frac{V_1 \times (1 - N_t) - V_2}{V_1 \times (1 - N_t)} \times 100$$

Where:  $V_1$  = original bacteria count of test group;  $V_2$  = bacteria count after treatment of test group.



**Test Results** 





## GUANGZHOU TESTING CENTER OF INDUSTRIAL MICROBIOLOGY TEST REPORT

Date Received: Sept. 14, 2018 Date Analyzed: Sept. 26, 2018

Number of Sample		Time		(	Control Group		Test Group		W.
	Test Strain		Test Number	Original Bacteria Count $V_0$ (cfu/m $^3$ )	Bacteria Count after Treatment $V_t$ (cfu/m $^3$ )	Natural Decay Rate N <sub>t</sub> (%)	Original Bacteria Count V1 (cfu/m³)	Bacteria Count after Treatment $V_2$ (cfu/m <sup>3</sup> )	Killing Rate $K_i$ (%)
KJ20181600(B)-1	Escherichia coli	60	1	$1.08 \times 10^{5}$	$5.54\times10^4$	48.70	$1.06 \times 10^{5}$	$3.39\times10^3$	93.77
			2	$1.03 \times 10^{5}$	$5.38 \times 10^4$	47.77	1.15×10 <sup>5</sup>	$3.57\times10^3$	94.06
		3	3	$1.12 \times 10^{5}$	$5.63 \times 10^4$	49.73	$1.02 \times 10^{5}$	$2.93 \times 10^{3}$	94.29
			Mean	)			.8	型田	94.04
			**:	* End of rep	ort***		)		

Date Reported

